

MODULE REPLACEMENT INSTRUCTIONS

! IMPORTANT! - Read all instructions before replacing the modules.

! NOTE! - Modules can be replaced without removing the lightbar from the vehicle.

# COMPATIBLE PART CODES

308.R24CR65 / 308.R24CR65MAG / 308.R30CR65 / 308.R42CR65 / 308.R48CR65 / 308.R60CR65

# **TOOLS REQUIRED**

2.5mm Allen Key for side modules (NOT supplied) 3mm Allen Key for end modules (NOT supplied)

! CAUTION ! - Disconnect the battery before replacing the module to prevent accidental shorting and/or electrical shock.

### MODULE REPLACEMENT

308.R6MOD - SIDE MODULE

308.R8CMOD - END MODULE





- 1. Remove the screws relating to the desired module
- 2. Slide out the module you wish to replace
- 3. Unplug the module connector
- 4. Plug in the replacement module using the connector
- 5. Slide the replacement module into position
- 6. Fasten the removed screws to secure the module



## MODULE LENS CLEANING

Occasional cleaning is recommended to ensure optimal liaht output.

Although tough, polycarbonate scratches easily, so take care when cleaning.

Clean lens with soap and water or a lens polish using a soft cloth.

! WARNING! - Do NOT use solvents as they may damage the lens.

! WARNING ! - Do NOT use high-pressure washers or automatic car washers. This lightbar is rated IP67.

www.dun-bri.com +44 (0)1763 274185 sales@dun-bri.com