


INSTALLATION + OPERATING INSTRUCTIONS




! IMPORTANT ! - Read all instructions before installing and operating the alarm. This alarm must be installed by a qualified automotive technician. Failure to do so may void your warranty.

258.001

| | |
|----------------------------|--|
| Output Type | Spoken Words |
| Message | 'Beep Beep, Beep - Warning, this vehicle is reversing' |
| Features | Night Silent (see wiring diagram) |
| dB(A) | 97dB(A) |
| Voltage | 12-24V |
| Fitting | 2 Bolt |
| Connection | Fly Lead (2 wires) |
| Approval(s) | ECE R10 |
| IP Rating | IP67 |
| Dimensions (l) x (h) x (d) | 103mm x 66mm x 45mm |

DBG SPEAKING REVERSE ALARM

WIRING DIAGRAM



*** ALTERNATE WIRING FOR NIGHT SILENT FUNCTIONALITY** - Connect the Reverse Alarm -VDC (BLACK WIRE) to the Tail Light +VDC (RED WIRE). Otherwise, connect the -VDC to Ground to use the alarm at all times of the day.

MOUNTING + FITTING INSTRUCTIONS

Carefully unpack and inspect the alarm before installing to ensure there is no damage.

Plan all cable routing before attempting installation and ensure voltage compatibility.

Mount the alarm horizontally facing directly rearward for maximum efficiency.

Fit in a position that will not be effected by dirt, flying objects, impacts and direct water streams.

Ensure there are no obstructions blocking the sound waves of the alarm.

If the alarm slides or moves easily, a proper installation has NOT been attained.

! CAUTION ! - Disconnect the battery before wiring up the alarm to prevent accidental shorting and/or electrical shock.

! CAUTION ! - When drilling into the vehicle surface, make sure the area is free from anything that could be damaged, including any electrical wires, fuel lines, upholstery, etc.

! WARNING ! - Do NOT use high-pressure washers or automatic car washers. This alarm is rated IP67.

! WARNING ! - Do NOT fit near high temperature zones around the engine or exhaust.

TROUBLESHOOTING

All alarms are performance tested prior to shipment. However, should you encounter a problem at any time, please refer to the below table for repair solutions. Additional information may be obtained from the manufacturer if required.

| Problem | Probable Cause | Solution |
|-------------------------|----------------|--|
| Alarm does not function | Wiring error | Ensure alarm wiring is correct and all wire connections are secure |
| | Blown fuse | Check wiring and fuse. Replace fuse |

MANUFACTURER'S WARRANTY

Dun-Bri Services Ltd warrants that on the date of purchase this product conforms to the specifications (available on request). Dun-Bri Services Ltd further warrants that this product is free from defects in materials and workmanship for 12 months from the date of purchase. Dun-Bri Services Ltd will at its discretion, repair or replace any product found to be defective, subject to the Limited Warranty.

Damage to parts or products resulting from tampering, accident, abuse, misuse, negligence, unapproved modifications, fire or other hazard, improper installation/operation or failure to maintain in accordance with the reasonable maintenance procedures set forth in Dun-Bri Services Ltd's installation and operating instructions shall void the Limited Warranty.

Verbal statements or representation about this product made by salespersons, dealers, agents or other representatives do not constitute part of the warranty agreement. This Limited Warranty may not be amended or extended except by written agreement, signed by an authorised official of Dun-Bri Services Ltd, which expressly refers to this Limited Warranty.

EXCLUSION OF OTHER WARRANTIES

Dun-Bri Services Ltd offers no further warranties, express or implied. The implied warranties for merchantability or fitness for a particular purpose are hereby excluded and shall not apply to the product. The buyer's sole and exclusive option in contract, tort, or any other practice against Dun-Bri Services Ltd regarding the product and its use shall be the replacement or repair of the product as described.

LIMITATION OF LIABILITY

In the event of liability for damages arising from this Limited Warranty or any other claim related to Dun-Bri Services Ltd's products, the liability for damages shall be limited to the amount paid for the product at the time of purchase. Under no circumstances shall Dun-Bri Services Ltd be liable for lost profits, the cost of substitute equipment or labour, property damage, or other special, consequential, or incidental damages based upon any claim for breach of contract, improper installation or negligence. Dun-Bri Services Ltd shall not be liable for any claim even if Dun-Bri Services Ltd or its representatives has been advised that damages of this nature are sought. Dun-Bri Services Ltd shall have no further obligation or liability with respect to the product or its sale, operation and use. Dun-Bri Services Ltd neither assumes nor authorises the assumption of any obligation or liability in connection with this product.